

EDGE OF DOOR

Per exit device instructions

EXIT DEVICE HORIZONTAL CENTERLINE

3/16" (5mm) DEEP outside only

5/32" (4mm)

2-3/8" (60 mm)

2-5/8" (67 mm)

Ø 2-1/8" (54mm)

Ø 5/16" (8mm)
5/8" (16mm) DEEP outside only

EXIT DEVICE BACKSET VERTICAL CENTERLINE

